



# Pool Sealer

## Description

An inexpensive sealer for leaking pools where seepage through general porosity or thinness of the plaster is suspected. Pool Sealer will not seal plumbing leaks or structural cracks.

## Application

1. Put the Multiport Valve handle of your sand filter to a position which allows the water to circulate without passing through the filter (Bypass/Recirculate).
2. Add 25 litres of Pool Sealer evenly over the surface of the pool and stir in using the pool brush on a long handle.
3. Let the pump run for about one week as described in 1 above. During this time brush the floor of the pool frequently to keep the sealer in circulation. It is heavier than water and tends to settle to the floor of the pool.
4. After one week switch off the filter and allow the sealer to settle on the floor over a period of two days.
5. Now, using your manual vacuum brush / eight wheeler, vacuum to waste.
6. Repeat the vacuuming to waste the following day.
7. Move the Multiport Valve handle back to the filter position and resume filtering and chemical dosing in the normal way.

## Dosage

25 litres/75 000 litre pool.